

CITYSTORM USER GUIDE

Congratulations on your purchase of a GIANT Citystorm. GIANT Citystorm represents the latest in design and engineering, and also requires special care. While Giant Bicycle engineers have used the best quality, most durable and lowest maintenance materials in this Citystorm, you must follow certain guidelines to attain optimal performance and proper wear characteristics.

⚠ WARNING Failure to follow these Instructions will void your warranty, and may result in hidden damage to the Citystorm. Damage to the Citystorm can cause loss of structural integrity, which may result in serious personal injury.



Front light

How to replace the battery

Step 1:  Turn 90° counterclockwise with a coin to loosen the battery holder


Step 2:  Take out the battery holder from the stem

Step 3:  Replace the battery (AA SIZE) with a new one.

⚠ CAUTION The battery has polarity (+/- sides), so be sure to install the battery with the + side upward as shown in the diagram.

Rear light


How to replace the battery


Step 1:  Take out the cover with coin.

Step 2:  Replace the battery (SIZE AAA) with a new one.

⚠ CAUTION The battery has polarity (+/- sides), so be sure to install the battery as shown in the diagram.

How to install the rear light onto saddle

Step 1:  Loosen the rear light fixing bolt with 4mm Hex key.
Remove the rear light and fixing link.



Step 2:  Install onto saddle IN THE FOLLOWING ORDER: one rear light, one fixing bolt.
Tighten the rear light fixing bolt with 4mm Hex key.
Tightening torque: 2.9-5.8Nm

CITYSTORM USER GUIDE

Stem watch

How to use stem watch?





Method of display the date:
Press the button A to display the DATE.


Method to display the time:
Press the button A twice to display the time.

Method of setting:
Step1: Press the button B twice to enter setting mode.
Step2: Press the button A to change the value.
Step3: Press the button B to confirm the setting and move to the next digit to be set.
Step4: Set each digit in order from date to time.
Step5: After the minutes have been set, press the button A to return to the normal display.

How to replace the battery?

Step 1:  Loosen the stem watch fixing bolt with 3mm Hex key.
Tightening torque: 1.9-3.4Nm

Step 2:  Push the stem watch up with 3mm Hex key.

Step 3:  Loosen the cover fixing screw with screwdriver.

Step 4:  Replace the battery (LR921) with a new one.


CAUTION The battery has polarity (+/- sides), so be sure to install the battery with the + side upward as shown in the diagram.

Lock

How to use lock

Step 1:  Adjust dials to let your combination align with the mark.

Step 2:  Then release the lock from the bike.

Step 3:  After deciding how to lock the bike, push the lock in and turn to the lock position.

Warranty

Please refer to the Giant Owner's Manual or visit our website: www.giant-bicycle.com for complete provisions of the warranty.



CITYSTORM SERVICE INSTRUCTION

Read these instructions carefully before using, and follow them for correct use.




Front light

How to replace the battery

Step 1:  Turn 90° counterclockwise with a coin to loosen the battery holder


Step 2:  Take out the battery holder from the stem

Step 3:  Replace with new battery (AA SIZE).

CAUTION The battery has polarity (+/- sides), so be sure to install the battery with the + side upward as shown in the diagram.

Front light


How to disassemble the front light

Step 1:  Pull out the front light from the head tube.


Step 2:  Disconnect the front light from the connector.


How to assemble the front light

Note: You must install the front light first before install the handlebar stem.

Step 1:  Rotate the front fork and pull out the wire at the same time, make sure the length > 150mm.

Step 2:  Install the handlebar first and then connect the front light connector.

Step 3:  Install the front light to the head tube; make sure the button is at the top position.



CITYSTORM SERVICE INSTRUCTION

Stem watch

How to use stem watch?



Method of displaying the date:

Press the button A to display the DATE.


Method to display the time:


Press the button A twice to display the time.


Method of setting:

- Step1: Press the button B twice to enter setting mode.
- Step2: Press the button A to change the value.
- Step3: Press the button B to confirm the setting and move to the next digit to be set.
- Step4: Set each digit in order from date to time.
- Step5: After the minutes have been set, press button A to return to normal display.

How to replace the battery?

Step 1:  Loosen the stem watch fixing bolt with 3mm Allen key.
Tightening torque: 1.9-3.4Nm

Step 2:  Push the stem watch up with 3mm Allen key.

Step 3:  Loosen the cover fixing screw with screwdriver.


Step 4:  Replace the battery (LR921) with a new one.

CAUTION The battery has polarity (+/- sides), so be sure to install the battery with the + side upward as shown in the diagram.

Rear light



How to replace the battery

Step 1:  Take out the cover with coin.

Step 2:  Replace with new battery (SIZE AAA).

CAUTION The battery has polarity (+/- sides), so be sure to install the battery as shown in the diagram.


How to install the rear light onto saddle


Step 1:  Loosen the rear light fixing bolt with 4mm Allen key.
 Remove the rear light and fixing link.


Step 2:  Install onto saddle IN THE FOLLOWING ORDER: one rear light, one fixing bolt.
Tighten the rear light fixing bolt with 4mm Allen key.
Tightening torque: 2.9-5.8Nm


CITYSTORM SERVICE INSTRUCTION

Installation of the hook


Step 1:  Loosen the cable fixing bolt.
Make sure that the quick release of the brake is in open position.

Step 2:  Insert the front brake cable through the hook.

Step 3:  Hold the front brake cable and shifter cable with hook.
These two cables should parallel.

Step 4:  Adjust the hook in the suitable position.

Installation of the front fork


Step 1:  Insert the front fork into head tube and pull out the wire for the front light from the head tube.


Lock

How to use lock

Step 1:  Adjust dials to let your combination align with the mark.

mark

Step 2:  Then release the lock from the bike.

Step 3:  After deciding how to lock the bike, push the lock in and turn to the lock position.

How to replace the lock

Prior to dismantling the lock
Remove front light from the head tube.(see page 1)
Remove front fork

Step 1:  Loosen the lock fixing bolt with 5mm Allen key.
Tightening torque: 4.9-7.8Nm

Step 2:  Pull out the lock

Step 3: Repeat Steps 1~2 in reverse to install the new lock

Warranty

Please refer to the Giant Owner's Manual or visit our website: www.giant-bicycles.com for complete provisions of the warranty.